

**A - Foot Base**  
**B - Fiberglass Pole**  
**C - Snap-Lock Profile**

**Note :** Always roll graphic "image side out" during storage




**1**  
 Remove Express Stand from bag and slide metal foot base into bottom profile of the graphic.




**2**  
 Assemble pole. Attach top pole connector to top profile of the graphic.



**3**  
 Flex pole and insert bottom of pole into the hole in the metal foot base.



**4**  
 Display can be repositioned after set up.



**5**  
**OPTIONAL**  
 To attach light place connector into top of pole.